
HORNER SHEARING

STRIKE

TECHNICAL DRAWING



NO.	PART NO.	DESCRIPTION	QTY
1	H15-411	Left Hand Fork	x1
2	H15-412	Right Hand Fork	x1
3	H15-413	Gauge Plate	x1
4	H15-414	Fork Detail	x1
5	H12-028	Tension Link Spring Screw	x2
6	H15-417	Tension Link Spring	x1
7	H15-418	Tension Link Spring Bush	x1
8	H15-419	Crank Roller	x1
9	H15-420	Crank Spindle	x1
10	H15-421	Comb Screw	x2
11	H15-422	Housing Cover Screw	x2
12	H15-423	Fulcrum Post Nut	x1
13	H15-424	Fulcrum Post	x1
14	H15-425	Head Retaining Screw	x2
15	H12-003	608 ZZ Bearing	x2
16	H15-426	Crank Spacer	x1
17	H15-427	Drive Gear	x1
18	H15-428	Crank Spindle Circlip	x2
19	H15-429	Bare Head	x1
20	H15-430	Housing Cover	x1
21	H15-431	Key	x1
22	H15-432	Lid Bush	x1

NO.	PART NO.	DESCRIPTION	QTY
23	H12-009	Tension Retaining Ring	x1
24	H15-434	Sliding Sleeve	x1
25	H15-435	Tension Nut	x1
26	H15-436	Casing Screw	x4
27	H15-438	Switch Actuator	x1
28	H15-439	Casing (Pair)	x1
29	H15-440	Switch Locator	x1
30	H15-441	Lithium Ion Battery	x1
31	H15-114	Head Retaining Nut	x2
32	H15-443	Motor	x1
33	H15-444	Motor Pad	x1
34	H15-445	Switch To Motor Wire	x1
35	H15-446	Connection Plate To Motor Wire	x1
36	H15-447	Connection Plate To Switch Wire	x1
37	H15-448	Switch	x1
38	H15-449	Battery Connection Plate	x1
39	H15-450	Battery Clip Pin	x1
40	H15-451	Battery Clip	x1
41	H15-452	Wrist Cord	x1
	H15-456	Battery Charger (UK Plug)	x1
	H15-457	Battery Charger (EU Plug)	x1